

GREEN MOUNTAIN WOODWORKS BUTCHER BLOCK INSTALLATION INSTRUCTIONS:
Mounting must allow butcher block slab to expand and contract naturally with environmental changes. Snug mechanical fastener centered through oversized hole. No glues or adhesives.

(1) DRILL OVERSIZED THROUGH HOLE THROUGH STRUCTURAL CABINET SURFACE, STRUT OR MOUNTING PLATE. HOLE DIAMETER AT LEAST 3x SCREW DIAMETER

(2) DRILL PILOT HOLE FOR LAG SCREW CENTERED WITHIN THROUGH HOLE BELOW IT NO MORE THAN HALF DEPTH OF BUTCHER BLOCK

(3) INSERT LAG SCREW WITH FENDER WASHER TO SNUG- DO NOT OVER TIGHTEN. ALLOWS BUTCHER BLOCK TO EXPAND & CONTRACT WITHOUT STRESS TO BLOCK OR STRUCTURE.

